
Boat Building Basics



How To Build Your Cardboard Boat

Construction Rules

- The ENTIRE boat must be built of cardboard, duct tape, and one-part polyurethane.
 - Only exceptions are the paddles & decorations
 - Use Cardboard boxes, "blocks", carpet tubes
 - NO pre-treated cardboard allowed
 - No Sona-Tubes, waxed or 'treated' cardboard
 - NO wood, plastic or fiberglass
 - NO caulking compounds or two-part/mixed adhesives
 - NO wrapping in duct tape, plastic or fiberglass
 - Duct tape may be used to reinforce seams

Construction Rules (continued)

- Waterproof the boat with Varnish, Paint or Polyurethane (onepart, paint-like substance)
- Decorations are encouraged as long as they don't effect structural strength or buoyancy
- The crew compartment CANNOT be enclosed so as to interfere with escape
- Every crewmember <u>12 and under must wear a personal</u> floatation devise (PDF) and proper footwear







Construction Materials


Permissible Materials

- Corrugated Cardboard
 - Appliance or grocery stores
- Cardboard "blocks"
 - Furniture stores
- Cardboard Tubes
 - Carpet/linoleum stores
- Fastening material
 - Duct or masking tape
 - Liquid nails adhesive
 - Latex Paint, Varnish


Materials NOT Allowed

- Wood, Styrofoam
- Plastic sheathing
- Fiberglass
- Sona-Tubes, coated cardboard
- Silicon, Wax, Tar
- Caulking compounds
- Metal
- Staples, clamps, screws
 Judges decide on the
 Interpretation of the rules


Construction Materials (examples)



Cardboard Block (2-3" thick)



Carpet Tube (about 4 ½" dia.)




Cardboard Box - cut open

Cardboard Boat Design

- Consider size building & transporting
 - Big enough to hold crew, small enough to carry
 - Wider is better, but still be able to paddle
 - No surfboard style designs are allowed
 - Rafts are allowed
 - Consider total weight of all materials when wet
 - EVERYTHING must be removed from the lake
- Boat decorations and crew costumes are encouraged use your imagination you will be awarded for your creativity!

Cardboard Boat 'Physics'

"How much will you sink?" - Displacement



Weight of Water = 62.4 pounds/cubic-foot

Water Displaced($ft^{3)}$ = Weight-of-boat-&-people-lbs 62.4 lbs/ ft^{3} -H20


Depth(ft) boat sinks

Example:

Box boat, 3 ft X 6 ft, 1ft tall (high) Boat volume = 3' X 6' X 1' = 18 ft³ Boat displacement = 18 ft³ X 62.4 lbs/ft³ = 1123.2 lbs Which equates to 93.6 lbs per inch of boat height


More Cardboard Boat 'Physics'

"Wider is Better" - Center of Buoyancy



Even More Cardboard Boat 'Physics'

Movement Through the Water



Cardboard Boat Design Suggestions

- Set the Design Goal: Fun, Speed and Appearance
- Sketch out your design
 - build a scale model from manila paper:
 - estimate materials or plan how to use what you have
 - plan out what construction techniques will be used
- 1'x1'x3' box: will float 187 lbs.
 - if it'll hold you, it's big enough to float
- Flat bottom, sit-to-paddle & canoe styles are the best/easiest
- Rudders help keep you straight but make turning difficult and adds complexity to your design.

More Cardboard Boat Design Suggestions

- Long boats go fast but are harder to turn
- Short boats (<8') are difficult to keep straight
- Best Length: 8-12 feet
- Best Height: 18 inches
 - allows room to sit/kneel & still paddle over the edge
- Best Width:
 - 18"- 30"(max) for 1 person
 - 48" wide for 2 people side by side
- Kneeling is a "power" position but sitting is more comfortable

Construction Tips & Techniques I

- Cover all edges of cardboard acts like siphon
- Cardboard Tubes make great frames
 - Cut for joining & bending
 - Fasten tubes together
- Cardboard Hull
 - 1-2 layers, fasten & cover the seams
 - With 2 layers, overlap the seams & polyurethane in between
 - Decorate, paint & varnish
- Reinforce the area where you sit, kneel or stand


Construction Tips & Techniques II

- Carpenter's glue and liquid nails work well
 - hot-melt glues will melt in the heat and sun
- Duct tape only non-painted surfaces (tubes or frame that will be covered)
 - Duct tape shrinks when painted
 - Duct tape should be covered with masking tape if you need to paint it
 - Clear tape melts when painted
 - Masking tape works well on glued edges & seams
 - Kraft paper with spray adhesive may also be used

Construction Tips & Techniques III



Solid Tube Frame




Center/Cross Beam Frame


FRAMES

CONNECTING TUBES

Cardboard Wrapper for Tubes End-to-End




Cardboard Wrapper for Tubes At Right-Angles




Construction Tips & Techniques IV


FRAME ANGLES



V-Shaped Cuts




Multiple Cuts for Sharper Angles



TUBE CUTTING TEMPLATE

Construction Tips & Techniques V




FOLD & OVERLAP CARDBOARD AROUND CORNERS

Construction Tips & Techniques VI

Crease/Score a line for a nice

STRAIGHT FOLD



Construction Tips & Techniques VII

Multiple cardboard layers "glued" together on the sides strengthen the hull

Multiple trapezoid-shaped pieces "glued" together to form a "support block"

